TO: Kee Doery

KegLand Distribution Pty Ltd

410 Princes Highway, Noble Park, Vic 3174.



GunnLab Plastics Testing Pty Ltd. ABN 16 159 320 304 PO Box 403, Black Rock, Victoria 3193,

Phone +61 3 9077 6738,

Australia 1300 486 652 New Zealand 0800 486 652

www.gunnlab.com.au

## **OXYGEN TRANSMISSION TESTS OF O-RINGS**

SAMPLES RECEIVED: 19/12/2022.

1. TEST RESULTS	OXYGEN TRANSMISSION RATE (OTR): 23 °C (±1°C), 0% or 90% RH inside, 50% RH (±5) out. Calculated to 100% oxygen at 1atm pressure. cm³/day (Cubic centimetres of oxygen per 24 hours through one O-ring)
White O-rings fitted to supplied keg-top	10.4 (@0% RH), 12.1 (@ 90% RH) Mean <b>11.3</b> cm³/day
Yellow O-rings fitted to supplied keg-top	0.43 (@0% RH), 0.39 (@ 90% RH) Mean <b>0.41</b> cm³/day

## 2. NOTES:

- 2.1 We expect that most (or virtually all) of the measured transmission is occurring through the O-rings. However, we have not attempted to measure the transmission (if any) occurring through the keg in/out fittings, pressure valve etc. Any such transmission from fittings etc. would be included in the measurement.
- 2.2 Results are reported on a 100% oxygen basis, which is the convention for published OTR data. Transmission in normal air (21% oxygen) would be 21% of the above results.
- 2.3 Oxygen transmission of both samples appears to be unaffected by changes in test humidity (RH).

## 3. TEST METHOD:

3.1 OTR: Based on ASTM F1307-02(2007), using Mocon Ox-Tran 2/22 and/or 2/21 instruments.

Test gas was a certified N<sub>2</sub>/O<sub>2</sub> mix for the white O-ring, room air for the yellow O-ring. All results were calculated to 100% oxygen at 1 atm. pressure.

Test time was about two days per test. Instrument calibration was done with Mocon standard reference films. OTR test uncertainty: No information available for this variation of the method.



Photograph of keg-top connected to Ox-Tran 2/22 test instrument.

Bruce Gunn. **GunnLab®** 

© GunnLab, 2023 Page 1 of 1